Yaris ECM

Connector A21

1	+B2 EFI Relay Contact		21	FAN (Fan #1 Relay)		41	CANH				
2	+B EFI Relay Contact		22	FANA (Fan #2 Relay)		42	VPMP Evap Can Pump Module				
3	+BM ETCS Fuse		23			43					
4			24	W Ground for MIL LED		44	MREL EFI Relay Coil				
5			25			45					
6			26	ODMS Trans Control SW		46					
7	FC C/OPN Relay Coil		27	TC		47					
8	SPD From Meter		28	IGSW IGN Fuse		48	STA P/N Pos SW or Clutch SW				
9	EOM Key ECU EGND		29			49	CANL				
10	IMO Key ECU EFII		30			50					
11	IMI Key ECU EFIO		31	ELS Light Ctrl SW Input		51					
12			32	EC Ground		52					
13	ACCR ACC Cut Relay Coil		33	ELS3 DEF Relay Contact		53					
14	STSW Ignition Switch		34	MPMP Evap Can Pump Module		54					
15	TACH		35	ST1- Stop Lamp SW		55	VPA Acc Pos Sensor				
16			36	STP Stop Lamp SW		56	VPA2 Acc Pos Sensor				
17			37			57	VCPA Acc Pos Sensor				
18			38			58	VCP2 Acc Pos Sensor				
19			39			59	EPA Acc Pos Sensor				
20	BATT EFI Fuse		40	CCS Cruise Control		60	EPA2 Acc Pos Sensor				

Connector C20

1			41	M- Throttle Body M-		81	IGF1 Iginition coils		121	NE- Crank Pos Sensor	
2			42	M+ Throttle Body M+		82	IGT4 Iginition coils		122	NE+ Crank Pos Sensor	
3			43	ME01 Ground		83	IGT3 Iginition coils		123	OC1- Cam Timing Oil Ctrl Valve	
4			44	E02 Ground		84	IGT2 Iginition coils		124	NT- Speed Sensor (turbine)	
5			45	E01 Ground		85	IGT1 Iginition coils		125	NT+ Speed Sensor (turbine)	
6			46	E04 Ground		86	E03 Ground		126		
7			47	HT1B O2 Sensor B1S2		87	EX1B O2 Sensor B1S2				
8			48			88	ETHA Mass Air Flow Meter				
9			49	PRG VSV Purge		89					
10			50	ALT Generator M		90					
11			51			91	ETA Throttle Body E2				
12			52	STAR P/N Pos SW or Clutch SW		92					
13			53	R P/N Pos SW		93					
14			54	N P/N Pos SW		94	EPPM Evap Can Pump Module				
15			55	2 P/N Pos SW		95	ETHO ECT Solenoid				
16			56	D P/N Pos SW		96	ETHW Coolant Temp Sensor				
17			57	SLU+ ECT Solenoid		97	THW Coolant Temp Sensor				
18			58			98					
19			59			99	G2+ Cam Pos Sensor				
20			60			100	OC1+ Cam Timing Oil Ctrl Valve				
21			61			101					
22			62			102					
23			63	GE01 Throttle Body Shield		103					
24			64	OX1B O2 Sensor B1S2		104	E1 Ground				
25			65	THA Mass Air Flow Meter		105	#40 Fuel Injector #4				
26			66			106	#30 Fuel Injector #3				
27			67	VCTA Throttle Body VC		107	#20 Fuel Injector #2				
28			68			108	#10 Fuel Injector #1				
29			69			109	HA1A AF Ratio Sens B1S1				
30			70	VCPP Evap Can Pump Module		110	KNK1 Knock Ctrl Sens Bank1				
31			71	PPMP Evap Can Pump Module		111	EKNK Knock Ctrl Sens Bank1				
32			72	THO1 ECT Solenoid		112	A1A+ AF Ratio Sens B1S1				
33			73	P P/N Pos SW		113	A1A- AF Ratio Sens B1S1				
34			74	L P/N Pos SW		114	VTA2 Throttle Body VTA2				
35			75	SLT- ECT Solenoid		115	VTA1 Throttle Body VTA				
36			76	SLT+ ECT Solenoid		116	E2G Mass Air Flow Meter				
37			77	SLU- ECT Solenoid		117					
38			78	S2 ECT Solenoid		118	VG Mass Air Flow Meter				
39			79	S1 ECT Solenoid		119					
40			80	ST ECT Solenoid		120					