■FUNCTION

1. General

The wireless door lock remote control system has the following functions:

Function	Outline
All Doors Lock	Pressing the lock button of the transmitter locks all doors.
All Doors Unlock (2-step Unlock)	Pressing the unlock button on the transmitter once unlocks the driver's door. If the unlock button is pushed again within 3 seconds, all doors unlock.
Automatic Lock Function	If no door is opened within 30 seconds and the ignition key is not in the ignition key cylinder after unlocking the doors by pushing the unlock button on the transmitter, all doors are locked again antomatically.
Answer Back Operation	The hazard light is flashed once when locking, and the hazard light is flashed twice when unlocking, to inform that the operation has been completed.
Panic Alarm Operation	Pressing and holding the panic button on the transmitter for approximately 0.8 seconds activates alarms. Pushing any button on the transmitter during the alarms cancels the alarms.
Transmitter Recognition Code Registration Function	● A maximum of 4 types of transmitter recognition codes can be registered in the wireless door control receiver. ● When 4 codes are already registered and a new code is registered, it is written over the oldest of the already registered codes.
Customized Body Electronics	For details, see BE-11

2. Transmitter Recognition Code Registration Function

The table below shows the 4 special coded ID registration function modes through which up to 4 different codes can be registered. The codes are electronically registered (written and stored) in the EEPROM. For details of the recognition code registration procedure, refer to the 2006 Yaris Repair Manual (Pub. No. RM00R0E).

Mode	Function
Rewrite Mode	Erases all previously registered codes and registers only the newly received codes.
Add Mode	Adds a newly received code while preserving any previously registered codes. This mode is used when adding a new transmitter. If the number of codes exceeds 4, the oldest registered code is erased first.
Confirm Mode	Confirms how many codes are currently registered. When adding a new code, this mode is used to check how many codes already exist.
Prohibit Mode	Deletes all the registered codes and prohibits the wireless door lock function. This mode is used when the transmitter is lost.