How to change the spark plugs on a 2008 Toyota Yaris

Gather the following supplies

1. 4 Iridium Spark Plugs
2. Spark plug wrench
3. Wrench Extension

Release hood lock located on the lower section of the dash between the door and the steering wheel.

Release hood latch under and alongside hood in front of car

Open hood and prop up hood with the hood prop rod



Remove the ignition coils

1. Locate and remove black cover (what is this called?) that has VVT written on it
2. Locate the four ignition coil packs and set on top of valve cover
3. Remove bolt that holds coil pack
4. Pull coil pack out



Change and replace spark plug one at a time

1. With extension and spark plug wrench unscrew the plugs from the cylinder head turning counterclockwise, and pull straight out
2. Do not adjust the spark gap
3. Put the replacement plug in turning clockwise
4. Tighten the spark plugs to 25 foot pounds of torque
5. Tighten the small bolts for the ignition coils to 10 foot pounds of torque

Replace black cover and tighten screws

Start engine.