90,000 Miles or [illegible]

- ☐ Replace engine air filter
- ☐ Replace engine oil and oil filter [1]
- ☐ Rotate tires

Inspect the following:

- ✓ Ball joints and dust covers
- ✓ Brake lines and hoses LS
- ✓ Brake linings/drums and brake pads/discs [4] LS
- ___ Drive belts
- ___ Drive shaft boots
- ___ Engine coolant [3]
- ___ Exhaust pipes and mountings
- ___ Front differential oil
- ___ Fuel lines and connections, fuel [illegible] and fuel tank vapor vent system
- ___ Fuel tank cap gasket
- ___ Radiator and condenser
- ✓ Steering gear box LS
- ✓ Steering linkage and boots LS
- ___ Transmission fluid or oil

Additional Maintenance Items for Special Operating Conditions [2]

Driving on dirt roads or dusty roads:

- ☐ Tighten nuts and bolts on chassis