

TIRE ROTATION


For maximum mileage, rotate your tires according to the vehicle manufacturer's recommendations (consult your vehicle owner's manual), or if not provided, rotate every 5,000 miles using a rotation pattern such as below (see "Radial Tire Rotation" in this manual).






TIRE WEAR—VISUAL CHECK


Check for obvious signs of wear.




Exposed tread bars (replace)



Irregular shoulder wear (have inspected)



Shoulder wear (have inspected)



Center wear (have inspected)

Place a penny in the tire tread grooves as shown. If you can see the top of Lincoln's head, the tire is worn out and needs to be replaced.

