
Installation is not hard at all. Just remove the driver side paneling by the tail light assembly and look for the plug/socket that is on the upper part that goes to the Third brake light. I dismounted and uncoupled the plug to facilitate the install. There are an orange wire and a white with black tracer on the smaller pins side. Cut the orange wire and the side that goes to the plug is connected to the blue wire. The other orange wire is connected to the red wire. The Black wire is connected to the White with black tracer wire. It is shown below and the explanation is harder to understand than the picture. I have the plug/socket disconnected. The Plug/socket was mounted where the red arrow is pointing.



Reconnect the plug .



Remount the plug/socket to the original location and dress the wires. You're DONE ! Step on the brakes, and the stoplights illuminate as before, but the third brake light blinks rapidly for 6 times, then goes solid on. If you release the brakes and apply them again before 8 seconds, it just lights like before. However after 8 seconds, when you reapply the brakes, it flashes, and then goes solid again. It HAS to get the attention of anyone behind you. . . .



While I was in there, I added a Hatch Light Switch, so that I can turn off the light with the hatch open.

