

Remote Control Mirror (w/o Automatic Retractable Mirror)
1
2
3
4
(ACC)
5A
ACC
13
3B
GR
F7
Outer Mirror Switch Assembly
8
B
Left
Right
Up
Down
Left/
Up
Right/
Down
Operation
Switch
Select
Switch
Left
Right
Left
Right
HL
HR
VL
VR
M+
E
5
2
4
3
6
7
V
L
R
B
W
W–B
8
B
9
B
FB4(A), FB5(B)
Junction
Connector
3
A
W
L
P
10
HF1
19
HF1
9
HF1
19
GF1
10
GF1
9
GF1
BE
B
P
B
SB
P
3
1
2
1
3
2
MH
MV
M+
MV
MH
M+
M
M
M
M
H6
Outer Rear View Mirror Assembly LH
G6
Outer Rear View Mirror Assembly RH
W–B
5
6A
F1