

Double Locking
1
2
3
4
(BAT)
5A
ECU–B
NO. 2
(BAT)
25A
D–D/L
F79(A), F128(B)
Double Lock Door Control Relay Assembly
+B
CPUB
DLPD
ACTS
ACTR
DLPP
DLPR
DLPL
MPX1
GND
Main Body ECU
<38–22>
G5
Front Door with Motor
Lock Assembly RH
H5
Front Door with Motor
Lock Assembly LH
I3
Rear Door with Motor
Lock Assembly RH
J3
Rear Door with Motor
Lock Assembly LH
DLSR
DL
UNDL
Double Lock
Position
∗1 : w/ Entry & Start System
∗2 : w/o Entry & Start System
∗3 : 5–Door
∗5 : Before Jul. 2014 Production
∗6 : From Jul. 2014 Production
∗7 : Before Mar. 2017 Production
∗8 : From Mar. 2017 Production