

REMOVAL

1. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**
2. **REMOVE INSTRUMENT PANEL FINISH PANEL END RH (See page ME-145)**
3. **REMOVE INSTRUMENT PANEL FINISH PANEL END LH (See page ME-145)**
4. **REMOVE INSTRUMENT CLUSTER FINISH PANEL (See page ME-145)**
5. **REMOVE INSTRUMENT CLUSTER CENTER FINISH PANEL SUB-ASSEMBLY (See page AC-250)**
6. **REMOVE RADIO RECEIVER ASSEMBLY**
   (a) Remove the 4 screws.
   (b) Disconnect the connectors and remove the radio receiver.





DISASSEMBLY

1. **REMOVE RADIO BRACKET RH**
   (a) w/ CD Player:
      (1) Remove the 4 screws and remove the radio bracket.



   (b) w/o CD Player:
      (1) Remove the 3 screws and remove the radio bracket.






2. REMOVE RADIO BRACKET LH

(a) w/ CD Player:

(1) Remove the 4 screws and remove the radio bracket.



(b) w/o CD Player:


(1) Remove the 3 screws and remove the radio bracket.

REASSEMBLY

1. INSTALL RADIO BRACKET RH


(a) w/ CD Player:

(1) Install the radio bracket with the 4 screws.



(b) w/o CD Player:


(1) Install the radio bracket with the 3 screws.





2. INSTALL RADIO BRACKET LH

(a) w/ CD Player:

(1) Install the radio bracket with the 4 screws.







(b) w/o CD Player:
(1) Install the radio bracket with the 3 screws.

INSTALLATION

1. **INSTALL RADIO RECEIVER ASSEMBLY**
   (a) Connect the connectors.
   (b) Install the radio receiver with the 4 screws.
2. **INSTALL INSTRUMENT CLUSTER CENTER FINISH PANEL SUB-ASSEMBLY (See page AC-258)**
3. **INSTALL INSTRUMENT CLUSTER FINISH PANEL (See page ME-148)**
4. **INSTALL INSTRUMENT PANEL FINISH PANEL END RH (See page ME-149)**
5. **INSTALL INSTRUMENT PANEL FINISH PANEL END LH (See page ME-149)**
6. **CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**
   Torque: 5.4 N*m (55 kgf*cm, 48 in.*lbf)